


- Please read this manual carefully and thoroughly before operation.
- This unit must be used correctly, according to the manufactures instructions.
- Please keep this manual in a safe place for future reference.

MINERAL ION WATER A CALIVATOR Mineral ion water Activator

ANSP-02

Directly connected to tap water type

OPERATION MANUAL



Thank you very much for purchasing our "ANESPA DX"

Please read the instruction manual carefully and thoroughly before using this unit, and then use it correctly and according to specified instructions. We assume no responsibility for failure, accident or damage caused by installation or use not described in the instruction manual.


Contents

1	Preparation on safety 1
2	Accessories 1
3	Option (not included) $$ 1
4	Structure and name of parts 2
5	Installation procedure 3-5
6	How to use 5
7	Standard specifications 5
8	Replacement the cartridge 6
9	After-sales Service Back of the book


1 Preparation on safety

- Before using this product or new cartridge, please discharge the water for two or three minutes.
- As the water having passed through the unit remove the chlorine, use it early without long storage.
- Do not let the water not compatible with Water Supply Law to pass through the unit. This may constitute a limiting factor of the original function of this product. Please note that we accept no responsibilities for such case.
- At the occasion of initial watering, some muddiness and bubbles appear, however, there is absolutely no harm to the human body.
- Do not freeze the water in the unit. During the winter season, if there is a fear of freeze-up, please let small quantity of water through.
- Though this product is designed for warm water, do not pass hot water (60°C or more) through.
- After passing water through, the unit increases in weight significantly. If you turn over or drop this product, this may lead to accident. Always fix the tip-resistant ring to the wall surface securely and attach it to the unit.
- If that is the case of turning-over in the wash place, install the location where there is no harm.
- If the unit has been unused for 2-3 days, let water flow 1-2 minutes prior to use.
- For the prevention of accident such as burn injury, before passing water through the unit, always adjust the water temperature and then use this product.
- When water supply works is being performed in the vicinity of installation location or rusty water appears, never use this unit. This
 may constitute a limiting factor of the original function of this product. Please note that we accept no responsibilities for such case.
- Please do not use as a drink.
- Always replace the cartridge with the replacement time as a guide (see page 5).
- For the disposal of the main unit and cartridges, please follow the local regulations of your area.


2 Accessories



3 Option (not included)




4 Structure and name of parts




5 Installation procedure

1 Remove existing shower head.




Install the attached water supply hose to the water inlet port at the unit and original mounting port of shower. At connecting water supply hose to the original mounting port of shower, when bore diameter of thread does not match, please use the adapter of attached mixed faucet side.




Water supply hose
Water inlet port


3 Fit attached tip-resistant ring (with suction cup) to the unit. (At mounting tip-resistant ring, take aim in advance at the position installing the unit.)



4 Peel the release paper on the plate for adsorption, put the suction cap on the wall surface and let absorb it securely.




Install attached outlet pipe on the bathtub side of selector cock.



Connect attached shower head to the shower hose.




Install the shower hose to the shower side of selector cock.




6 How to use

In case of using the shower

Turn over the selector cock to the left to open the faucet of mixed water cock.



In case of filling hot water (water) in bathtub Turn over the selector cock to the right to open the faucet of mixed water cock.



7 Standard specifications

■ IInit

Product Name / Type	ANESPA DX / ANSP-02
Dimensions W x Diameter: (mm)	130 x 346 (except water supply connection)
Main unit weight	1.9 kg (included twin cartridge)
Filtration flowing quantity	10 L/min
Normal working pressure	0.05-0.5 MPa
Maximum working temperature	60 °C
Cartridge performance (JWPAS J.210 test results)	Ability to reduce free residual chlorine (Concentration of free residual chlorine : 1 mg/L, water temperature : 40 °C)
Cartridge material	Activated carbon, nonwoven fabric, tourmaline
Cartridge replacement period	Clean water cartridge About 1 year (Replacement timing varies depending on the water quality and quantity consumed) Ceramic cartridge About 3 years (Replacement timing varies depending on the water quality and quantity consumed)
Accessories of this unit	Outlet pipe (1000 mm), Water supply hose (1200 mm), Shower hose (2000 mm), Shower head, Tip-resistant ring (with suction cup), Plate for adsorption, Water filter change seal, Adapter set, Operation manual, Spanner

8 Replacement the cartridge

How to remove 3 Remove the Tip-resistant ring tip-resistant ring. Remove ① Remove the the outlet pipe. shower hose. Outlet pipe Shower hose Remove the cartridge Cartridge housing. housing Spanner Base ⑤ Remove the old clean DIO water cartridge. clean water cartridge 6 Remove the old Old ceramic cartridge. ceramic cartridge Base

How to install 2 Put in the new clean water cartridge. New clean water cartridge ① Put in the new ceramic cartridge. New ceramic cartridge Base Fit up the tip-resistant ring and install suction cup to the plate for adsorption. Tip-resistant ring 6 Install the ⑤ Insert the shower outlet pipe. hose. Outlet pipe Shower hose ③ Install the cartridge Cartridge housing. housing Base

Tighten the fixing nut.

9 After-sales Service

Warranty

 Please make sure that the date of purchase and your dealer's name are entered on the accompanying Warranty card. Keep it in a safe place.

If you need repair during warranty period

For repairs, please contact your local dealer.
 (Please read the guarantee conditions carefully, as some repairs may not be covered under the warranty, depending on the situation.)

⚠ CAUTION You may be charged if your repair are for the following reasons.

- 1. Trouble resulting from handling in a manner that is not specified in the "Operation Manual".
- 2. Trouble or damage due to use of water other than municipal drinking water.
- 3. Trouble or damage due to natural disaster, such as, earthquake, fires or floods.
- 4. Dropping the product or caused in any traffic accident during transportation.
- 5. Replacement of consumable parts.
- 6. Failure to fill in the "Date of purchase" and "User's Name" and "Dealer's Name" in the warranty form.

If you need repair after warranty expiration

• Contact your local dealer. Repair may be available upon request at purchaser's expense.

Others

If you lose the warranty card, you cannot receive warranty service.
 Note that the warranty card will not be re-issued.

⚠ WARNING



Do not attempt to open or disassemble any part of the unit. Any consequence of such behavior shall not be compensated by the maker.

For questions and information, please contact your local dealer.